


INTERCONNECTION



KONGSBERG



DECK MACHINERY - ANCHORING, MOORING & TOWING

Interconnection for anchor windlass

We are constantly working on our equipment performance, quality and reliability. Despite this, sometimes due to external factors, such as bad weather condition, human errors or just component failure, we might happen to find ourselves in the situation where the anchor winch is not operative anymore and the anchor is laying at the bottom of the sea.

In a challenging situation like this, having an interconnection gives you another chance to get out of trouble, quickly and safely.

Features of interconnection

- The interconnection gives the possibility to use one of the two (2) anchor winches starter cabinets to lift either port side and/or starboard side anchor
- Even if one drive/starter is out of order, both anchors are still operational


THE SYSTEM INCLUDES:

- Interconnection cabinet
- Design
- Documentation


REQUIREMENTS:

- Enough space close to the existing anchor winches starter cabinets to install the interconnection cabinet
- Possibility to re-route the winch cables from starter to winch

NORMAL OPERATION



INTERCONNECTION OPERATION



Kongsberg Maritime
P.O.Box 483, NO-3601
Kongsberg, Norway

Switchboard: +47 815 73 700
Global support 24/7: +47 33 03 24 07
E-mail sales: km.sales@km.kongsberg.com
E-mail support: km.support@kongsberg.com